

## **Nec DS 1000/2000 and DSX**

From extension 300 (usually the operator's phone)

Do not lift the handset

Dial # 83 enter time HH MM SS & Press Hold enter date MM DD YYYY press hold press speaker to end