

NEC SV8100 Time Setting information

NEC SV8100 Time Setting information

To set the system Time:

1. Press the Speaker key.
2. Dial 728.
3. Dial two digits for the hour (24 hour clock, 13 = 1:00 PM).
4. Dial two digits for the minutes (00~59).
5. Press Speaker to hang up.