

Samsung Prostar 816 System

Changing the time on a Samsung Prostar 816 system can be done from any display phone with the handset on-hook. (Do not lift handset off hook while programming.)

1. Enable technician programming mode

- Press "#" - "PROGRAMMING" is displayed
- Dial "20" - "MMC ENABLED" or "MMC DISABLED" is displayed
- Dial the password (default - 1234) - if wrong password is enter "ERROR" is displayed
- Dial "1" to enter program mode
- Press "#"

2. Press "#" key - "PROGRAMMING" is displayed

3. Dial "55" - the display shows "YY MM DD W HH MM" and then the current date is displayed

4. Enter the new date

- YY = Last two digits of the year
- MM = Month (01 - 12)
- DD = Day of the month (01 - 31)
- W = Day of the week (1 -7 day of the week begins on Monday & ends on Sunday)
- HH = Hour (Use 24 hour clock)
- MM = Minutes (0-59)

5. Press "#" - new date is saved