

## Toshiba Strata DK Telephone System

Changing the time on a Strata DK system must be done from the "main" or primary phone. It is usually extension # 10, or # 200.

1. With the phone on-hook, dial intercom, #, 652 (depending on the system type, the # may or may not apply)
2. Enter the correct time using HH/MM/SS, like 07:24:00
3. Press redial